

# Application Note

## C004 Phase Locking Set up With Peer To Peer

HA502487C004 Issue B

AC30P/D V2.13 onwards

© Copyright 2018 Parker SSD Drives, a division of Parker Hannifin Ltd.

All rights strictly reserved. No part of this document may be stored in a retrieval system, or transmitted in any form or by any means to persons not employed by a Parker SSD Drives company without written permission from Parker SSD Drives, a division of Parker Hannifin Ltd. Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Parker SSD Drives cannot accept responsibility for damage, injury, or expenses resulting therefrom.

### WARRANTY

Parker SSD Drives warrants the goods against defects in design, materials and workmanship for the period of 12 months from the date of delivery on the terms detailed in Parker SSD Drives Standard Conditions of Sale IA058393C.

Parker SSD Drives reserves the right to change the content and product specification without notice.



## Requirements

---

### **Intended Users**

This Application Note is to be made available to all persons who are required to install, configure or service equipment described herein, or any other associated operation.

The information given is intended to enable the user to obtain maximum benefit from the equipment.

### **Application Area**

The equipment described is intended for industrial motor speed control utilising AC induction or AC synchronous machines.

### **Personnel**

Installation, operation and maintenance of the equipment should be carried out by qualified personnel. A qualified person is someone who is technically competent and familiar with all safety information and established safety practices; with the installation process, operation and maintenance of this equipment; and with all the hazards involved.

### **Hazards**

Refer to the Safety Information given at the front of the Product Manual supplied with every Parker SSD Drives product.

DRAFT

# C003 PHASE LOCKING SET UP WITH PEER TO PEER

## Abstract

---

This application note gives an example of setting up a phase locking application with the Phase locking application described in HA503284U008, using the Peer to Peer feature.

## Pre-Requisite

---

The pre-requisites are :

- a AC30P or a AC30D drive used as the master drive
- a AC30P or a AC30D drive used as the slave drive

## Introduction

---

Phase Control or Phase Lock, sometimes referred to as electronic gearbox, is a position trim of a slave drive to a speed to maintain the relative position between a master and a slave shaft or a precision ratio between the two shafts. The slave speed demand is composed of the master speed demand and a position trim from a counter of the accumulated differences between the Master and Slave Encoders.

The AC30P and AC30D includes the ability to use real-time peer-to-peer communications, over Ethernet, to pass the speed/position reference from one drive to another in the system.


One drive (configured to be the Master) generates a speed and position command.

It could be a Real Master, using the position information from an external encoder connected to the drive, or a Virtual Master, internally generating position.

All the other drives must have the Virtual Master functionality enabled, and must be configured as Slaves.

The following phase blocks are also available:

- Phase inch – progressive phase advance or retard on demand
- Phase move – pre-defined phase change, at set speed and acceleration, on demand
- Phase offset – adjustment of the relative phase between the Master and the slave.
- Phase tuning – facility for the injection of square speed or phase offsets to assist loop tuning.



## Phase Loop operation

The phase loop is a position loop.

The position demand is the sum of the reference position plus the offsets generated by the phase blocks belonging to the application layer.


The position feedback is the position from the encoder defined as the slave encoder.

The Position Loop works on a multi turn position. The error between the Master and the slave can be a multi turn error.

It contains a PI corrector ( no derivative action ), a feed forward term and an output saturation.

The feed forward term is the sum of the reference speed plus the speeds generated by the phase blocks.

The output feeds the speed loop.




# Phase Control Default application

Default application is available as RA503284U008\_001.prj


Default configuration is separated in 3 parts :

- first is dedicated to the phase control :
  - o phase blocks
  - o real/virtual master configuration
  - o phase loop ( position loop )
- second is dedicated to the I/Os and sequencing of the drive
  - o Digital I/Os
  - o Encoder(s) setting
  - o Master/slave selection
- third is related to the Peer To Peer control
  - o PTP and Peer To Peer
  - o Connection control


## Phase Control :




# I/Os and sequencing :



# Peer To Peer Control



# Step to Configure Both drives



## Setup Control Mode:

Selection of the control mode ( Vector control ) and selection of the encoder feedback for the speed loop control.

## Setup Encoder Feedback :

Depending of the encoder feedback selected :

- if MAIN SPD FEEDBACK Selected, an IO option pulse encoder is required and the settings of the encoder are done in **Setup::Inputs and Outputs::Option**
- if MAIN SPD FEEDBACK Selected, an IO Resolver option is required and the settings of the Resolver are done in **Setup::Inputs and Outputs::Option**
- if SYSTEM BOARD SLOT 1 or SLOT 2 is selected, a system board is required and the settings of the encoder are done in **Setup::Inputs and Outputs::SB Encoder Slot1** or **Setup::Inputs and Outputs::SB Encoder Slot2**

## Motor Nameplate parameters :

Enter the motor parameters

## Speed Loop Scaling:

Enter the scaling for the speed loop control. This value represents 100% speed

## Autotune :

Run Autotune.

## Pos Alignment :

Only required for PMAC motors, if the alignment has not been done mechanically in factory.  
Run Pos Alignment.

## Speed Loop :

By default, speed loop settings gives a safe control of the motor. For a better dynamic and behaviour, it may be better to try to optimize the speed loop settings.

## Real Master / Virtual Master:

Selection of the Real Master or Virtual Master mode for the Master drive

If Real Master; selection of the encoder input used as the Real Master. And also selection of the filters applied on the speed and acceleration

If Virtual Master, selection of the internal ramp and parameter associated to the generator.

Connection of the user input to the speed input of the Virtual Master block

Selection of the Slave mode for Slave drives

## PTP and Peer To Peer :


Configure PTP and Peer to Peer.

**Note** : The Peer to Peer module broadcasts data at a high rate, as such, when the Peer to Peer module is enabled it is recommended not to connect the inverters to a corporate or other sensitive network.

Verify Connection of the Ethernet link.

If using the Control of the Peer To Peer connection in the default application ( which is almost mandatory to keep in control the system in case of disconnection ), Set **up Application::PTP::Drive Id** with the correct number and verify **Virtual Master Ref::AllDrivesLocked** input is TRUE.





peerConnection\_ : ThisData1 ThisData2 could be used to transfer information through the peer to peer from one drive to the others.

peerMonitor\_ : data1 data2 are used to read this information transferred from this drive.

ThisData1, ThisData2, data1 and data2 are 32 bits type. BIT\_AS\_DWORD and DWORD\_AS\_BIT Conversion Functions may be used to pass binary information.

For example, a Start command can be passed through the peer to peer by connecting it to ThisData1 through BIT\_AS\_DWORD into the peerConnection\_, thisId=1 and be read by others drives by reading data1 Through DWORD\_AS\_BIT of the peerMonitor\_ connected to peerId = 1

### Gearing:

Setup Gearing A and Gearing B input to their values.

### Enable Position Loop:

Insure your drive is torque OFF.


Enable Position Loop( **Position Loop::Enable** = TRUE ).

To reset the Position Loop to the actual motor position, set **Position Loop::ResetTotal** to TRUE, then to FALSE.

By default, position loop settings gives a safe control of the motor. For a better dynamic and behaviour, it may be better to try to optimize the settings.

## Peer to Peer Control

---



**PTP** and **Peer\_To\_Peer** should be set up and Enabled ( for more details [please refer to the Drive Manual](#))

**PTP :**

The PTP will synchronize the internal clocks over the Ethernet to better than 1 microsecond. No external master is required for the PTP network; any of the inverters may become a PTP master.

The initial use of the PTP is for shaft locking applications using the Virtual Master or Real Master control.

**Note:** Currently up to 9 inverters are supported on a PTP network.

### Peer To Peer :

The Peer to Peer module is implemented in the AC30P and AC30D inverters and provides Ethernet communications between inverters.


The data sent is not accessible to the user. The initial use of the Peer to Peer module is for shaft locking applications using the Virtual Master or Real Master control and used in conjunction with the Precision Time Protocol (PTP).

**Note:** The Peer to Peer module broadcasts data at a high rate, as such, when the Peer to Peer module is enabled it is recommended not to connect the inverters to a corporate or other sensitive network.

In default configuration appears some others blocks used to control and give diagnostics about the Peer To Peer connection. This is to detect a disconnection or a loss of Peer To Peer connection in the chain between drives.

The output information '**AllLocked**' is TRUE when all drives are connected and the Peer To Peer connection is Safe.

'**AllLocked**' is FALSE when the drives are not connected. This output can feed **AllDrivesLocked** input of **Virtual Master Ref**.



Drive Id = 1

Drive Id = 2

The default configuration is designed for 2 drives connected together.

Each drive should contain this control feature.

Each drive is identified by a unique Id accessible by the GKP under **Application::PTP::Drive Id**. In the default application, Drive Ids are 1 and 2.

If the Peer To Peer connection is lost between drive 1 and drive 2, then the diagnostic **AllLocked** becomes FALSE. If connected to **Virtual Master Ref::AllDriveLocked**, then drives are informed that the peer to peer connection has been lost and can take on their side the correct decision to stop safely the motor.


If nothing else is added to the configuration, the drive will return in speed control mode and move back the motor to the user speed setpoint ( values of the speed setpoint feeding the speed loop in speed control mode, usual settings of a speed setpoint in **Parameters::Motor Control::Sequencing**) by using the system ramp acceleration/deceleration set up in the Ramp block ( **Parameters::Motor Control::Ramp** ).

When and if the Connection is recovered, than the motor will move back in position loop. All drives will then resynchronize themselves to the master position.

Below is an example of 5 drives connected together, with Drive Id from 1 to 5.




Each drive owns its own Id ( 1 to 5 , Application::PTP::Drive Id ), and should contain this control diagram in its application.




Below an example of a start command from the drive to others drives :

Drive Id=1 sends the start command




All others drives receive the start command from the drive Id = 1



## Inputs and Outputs

In the default application, Inputs are connected as below :



2 inputs Digin\_02 and Digin\_03 are connected to the Phase Inch Blocks to synchronize the Slave to the Master position. Rate and Rate scale parameters allows to control the change in position when the inputs are TRUE.

### User Speed Input :

In REAL MASTER mode : Encoder lines A and B connected to one of the Encoder inputs

In MASTER mode : **Virtual Master::Input** : user speed setpoint in %

In SLAVE mode : Peer to Peer Information

# Conditions to be in phase control

---

The phase control mode is in action when the output *Position Loop::Mode* = MASTER ABSOLUTE POSTION.

To Access this state :

- One of the Virtual Master mode should be selected : *Virtual Master Ref::Mode* = REAL MASTER, MASTER or SLAVE.
- PTP and Peer to Peer must be set up. *PTP::PTP\_Enable* = TRUE and *Peer to Peer::Peer\_to\_Peer\_Enable* = TRUE
- *Virtual Master Ref::AllDrivesLocked* input should be TRUE.
- Phase loop must be enabled : *Position Loop::Enable* = TRUE
- Torque on the drive must be switched ON.

DRAFT