



Bulletin MSG30-2903-INST

# Installation and Start-Up Manual

## Plugin Module for PCM (Pump control module)

Effective: September 1<sup>st</sup> 2019

Supersedes: -

Firmware PCM: PCM\_TC41\_07\_00\_00\_01\_504 and higher

Plugin Module Version: 01\_17\_504

---



Visit our homepage for additional support  
[parker.com/pmde](http://parker.com/pmde)



## Contents

<b>1</b>	<b>Plugin Modules - Introduction</b>	<b>2</b>
<b>2</b>	<b>Plugin Installation</b>	<b>2</b>
<b>3</b>	<b>Plugin Configuration</b>	<b>4</b>
<b>3.1</b>	<b>Transmit Rate – Master</b>	<b>6</b>
<b>3.2</b>	<b>Timeout – Master</b>	<b>6</b>
<b>3.3</b>	<b>Plugin Module start-up</b>	<b>7</b>
<b>3.4</b>	<b>Plugin Module Operational</b>	<b>7</b>

### 1 Plugin Modules - Introduction


Plugin modules are prescaled J1939 interfaces which can be added into IQAN applications. Plugin modules are distributed by Parker and are made available online.

- [Iqan.se/store](http://Iqan.se/store)
- [parker.com/ep2](http://parker.com/ep2)


They are provided as plugin module files (.idmx) which are installed using the library manager. When a plugin module has been installed it will be available in the add menu of the system layout view. Once it has been added to a project it can be connected to a J1939 bus. A plugin module has the same properties as J1939 modules plus a number of custom properties. It also has a property that defines which master module controls the plugin module (it can only be used by one master module). A plugin module has inputs and outputs just like a physical module. To use them they have to be added using the Add button in the block diagram under System Layout. When doing so a new channel is added to the application of the master module. This channel is either a Module Input Channel (MIC) or a Module Output Channel (MOC). If a plugin module is updated with a new version in IQANdesign it will be updated also in existing projects when they are opened (after a user confirmation). A project containing a plugin module can be used in IQANdesign even if the plugin module is not installed. This is accomplished by saving a copy of the plugin module within the project file.

### 2 Plugin Installation


Download the latest PCM Plugin version from the internet. Open the Library Manager in IQAN Design under Tools.




Toggle to tab Plugin Modules.





Add Category and name it as per your choice.



Tie in the just downloaded Plugin Module with "Add".




Select the just downloaded Plugin Module file on your directory.




**NOTICE**

Please mind the Plugin Module version shown either in the library manager or the system layout.

The Plugin appears in the Add button dialog for usage in the IQAN system layout.



Install as much as needed plugin modules by drag and drop and name them as per your choice. Connect them with the commanding IQAN Master module.




**NOTICE**

The Password to implement the Plugin module is "PCM" (case sensitive!).




**NOTICE**

4 Plugin modules / 4 PCMs are the maximum amount per BUS.




### 3 Plugin Configuration


The Plugin appears empty in the system layout. The corresponding masters module input channels (MIC) and module output channel (MOC) need to be connected by using the Add button or by using the right mouse dialog at the corresponding pin. All pins at the left side are inputs to the master (and outputs from the PCM). The pins at the right side are outputs from the master (inputs to the PCM).




Check the connection to the corresponding master module.




Add a Initialization function group.



Add a Initialization function group.



Create integer parameters for source adress, transmit rates and timeouts. Optionally set defaults and further connect them to the adjust items of the Plugin Module. Connect the just created integer parameter to the corresponding properties of the plugin module.







**NOTICE**

Source address is unique to a controller at a J1939 Bus. Please consider when using multiple PCMs. Optional source addresses are 165, 166, 167.

Add the necessary channels to the plugin module pins with the right mouse click dialog or the add button.



All channels are generated in the top level function group of the corresponding master application.




Unconnected output pins (right side) will internally use default values to the PCM (CAN Message).

Channel	Default
Pump_series_PLo	0 (P2)
Pump_size_PLo	1 (P2075)
Valve_type_PLo	0 (Code EC)

NO_pulses_rev_PLo	36 pulses/rev.
Gearbox_ratio_pmp_in_PLo	1.00
BWL_spd_fdbk_PLo	50
Valve_output_manual_PLo	25 %
Press_sensor_always_PLo	False
Leak_comp_displ_PLo	False
Spd_fdbk_ANA_PLo	False
Valve_press_comp_inactive_PLo	False
T_upramp_displ_PLo	0 ms
T_downramp_displ_PLo	0 ms
T_upramp_press_PLo	0 ms
T_downramp_press_PLo	0 ms
Valve1_delay_on_PLo	0 ms
Valve1_delay_off_PLo	0 ms
Valve2_delay_on_PLo	0 ms
Valve2_delay_off_PLo	0 ms
Fdbk_volt_min_PLo	2500 mV
Fdbk_volt_max_PLo	4300 mV
Valve_zero_point_PLo	0 %
P_gain_displ_PLo	150
I_gain_displ_PLo	200
D_gain_displ_PLo	50
I_lim_displ_PLo	20
I_window_in_frozen_displ_PLo	0,5
I_window_out_reset_displ_PLo	15

D_window_in_inactive_displ_PLo	0
P_gain_press_PLo	40
I_gain_press_PLo	150
D1_gain_press_PLo	200
I_lim_press_PLo	20
I_window_in_frozen_press_PLo	2
I_window_out_reset_press_PLo	50
D1_window_in_inactive_press_PLo	0
D1_window_handover_press_PLo	1000
D2_gain_press_PLo	200
D2_gradient_window_PLo	1000
D2_error_window_PLo	50
Displ_setp_idle_PLo	0
Press_setp_idle_PLo	15



The channels appear in the application root for further usage. Only matching channel formats and ranges can be connected to the just created plugin channels.




**NOTICE**

All channels of type real and integer are internally limited both for minimum and maximum. Inputs outside the specified range will be disregarded.

For reference of the matching type please see the CAN protocol in the PCM installation manual

(HY30-2902-INST) or the help dialog in the bottom right corner.



**3.1 Transmit Rate – Master**

The transmit rates Transmittate\_PDO1\_PLo and Transmittate\_PDO2\_PLo needs to be set between 10 an 100ms in an even number.



**RECOMMENDATION**

Recommendation: Fill in a multiplier of the sending Master cycle time.



**NOTICE**

An input above 100ms will be interpreted as 100ms. An input below 10 ms will be interpreted as 10ms.

**3.2 Timeout – Master**

The Timeouts Timeout\_PDO1\_PLi and Timeout\_PDO2\_PLi need to be set at least twice the adjusted PCM transmittate (Transmittate PDO1\_out,Transmittate PDO2\_out)

	PDO1	PDO2
Min. timeout - Master [ms]*	20	40
Max. timeout - Master [ms]*	150 (default)	200 (default)

### 3.3 Plugin Module start-up

PDO2 should be sent continuously (selecting control type, mode selection, Enables, etc.).

PDO1 should be sent in operational mode (Ctrl\_type\_PLo > 2) only.

SDO1-SDO8 can only be sent in setting mode only.

When starting up a PCM the **SDO1** needs to be sent at least once with correct application values to set the internal scaling and other internal parameters according to the connected pump.

This is only possible when the pump is in setting mode. (Enbl\_out\_PLo=false, Enbl\_PID\_PLo=true → PDO2)



**NOTICE**

The wired digital ins (Enable inputs) need to be set accordingly or need to be true.



**NOTICE**

Internal scaling values are stored internally in the nonvolatile memory so that they are preserved during power off.


Furthermore **SDO4** needs to be sent for the correct scaling of the displacement sensor.



**NOTICE**

Input for the parameter Fdbk\_volt\_min\_PLo, Fdbk\_volt\_max\_PLo and

Valve\_zero\_adjust\_PLo needs to be taken from each pump individually using the below shown pump tag attached to each pump.



Example: Pump tag

**SDO2, SDO3, SDO6, SDO7, SDO8** needs to be sent only when applicable in the application.



**NOTICE**

All SDO are sent with the write SDO<sup>\*1</sup>\_write\_PLo command.

\*1 = 1...4

### 3.4 Plugin Module Operational

After all configuration parameter are set (SDO1-SDO8), PDO2 is used to switch to operational mode (Ctrl\_type\_PLo = 1 or 2) and the set points can be sent with PDO1.



## Position notification regarding Machinery Directive 2006/42/EC:

Products made by the Pump & Motor Division Europe (PMDE) of Parker Hannifin are excluded from the scope of the machinery directive following the "Cetop" Position Paper on the implementation of the Machinery Directive 2006/42/EC in the Fluid Power Industry.

All PMDE products are designed and manufactured considering the basic as well as the proven safety principles according to:

- ISO 13849-1:2015
- SS-EN ISO 4413:2010

so that the machines in which the products are incorporated meet the essential health and safety requirements.

Confirmations for components to be proven component, e. g. for validation of hydraulic systems, can only be provided after an analysis of the specific application, as the fact to be a proven component mainly depends on the specific application.

**Dr. Hans Haas**

General Manger

Pump & Motor Division Europe



## **WARNING – USER RESPONSIBILITY**

**FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.**

This document and other information from Parker-Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalogue and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

## **Offer of Sale**

Please contact your Parker representation for a detailed "Offer of Sale".

**For additional information, spare parts or service requirements please contact:**

**Parker Hannifin Manufacturing Germany GmbH & Co KG**

MSG30-2902-INST/UK

Pump and Motor Division Europe

Neefstraße 96

09116 Chemnitz, Germany

Tel: +49 (0)371 - 3937 - 0

Fax: +49 (0)371 - 3937 - 488

Email: eP2-Support.PMD145@parker.com

parker.com/pmde

© Copyright 2019

All rights reserved

