



AC30V series Fan Control Application

HA502134U002 Issue 2
Technical Manual

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding



ENGINEERING YOUR SUCCESS.

**FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS
CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.**

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalogue and in any other materials provided from Parker Hannifin Corporation or its subsidiaries or authorized distributors.

To the extent that Parker Hannifin Corporation or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

The above disclaimer is being specifically brought to the user's attention and is in addition to and not in substitution to the Exclusions and Limitations on Liability which are set out in the terms and conditions of sale.



Fan Control Application

HA502134U002 Issue 2

© Copyright 2013 Parker Hannifin Manufacturing Limited

All rights strictly reserved. No part of this document may be stored in a retrieval system, or transmitted in any form or by any means to persons not employed by a Parker Hannifin Manufacturing Limited company without written permission from Parker Hannifin Manufacturing Ltd. Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Parker Hannifin Manufacturing Limited cannot accept responsibility for damage, injury, or expenses resulting therefrom.

WARRANTY

Refer to Parker Hannifin Manufacturing Limited Terms and Conditions of Sale. These documents are available on request at www.parker.com.

Parker Hannifin Manufacturing Limited reserves the right to change the content and product specification without notice.

Fan Control Application Manual

Description

The fan application provides speed control using a speed reference from either an analogue input terminal, a preset speed selected by digital terminals or, if a Real Time Clock (RTC) option is fitted, a preset speed selected by built-in time of day / day of week programmer.

Features

- Automatic belt breakage detection (abnormal load)
- Timed run function. Start/stop events can be programmed with different running speeds.*
- Skip frequencies to enable resonant points on the fan to be avoided
- Fire Mode. Run to destruction if commanded to do so.
- Preset speeds
- Power-up start
- Auto Start on non-zero setpoint
- Separate Manual Run and Auto Run digital inputs
- Catching a spinning load when fan is free-wheeling


* 7004-01-00 or 7004-03-00 option required

Requirements

To use the AC30V for fan control as described in this manual, the application RA502134U002 must be loaded into an AC30V series drive with firmware 1.3.2 or newer.



**Application 6:
"Fan Control"**
DEDICATED FAN CONTROL WITH SPECIFIC FAN
FUNCTIONALITY



4 Fan Control Application Manual

Inputs

Terminal	Function	Comment
ANIN 01 (X11/01)	SPEED SETPOINT	Speed Reference used when MANUAL RUN
ANIN 02 (X11/02)		Not used
DIGIN 01 (X13/02)	MANUAL RUN*	Run command for using the Analog Input as Setpoint
DIGIN 02 (X13/03)	AUTO RUN*	Run command for using the selected Preset Speed as Setpoint
DIGIN 03 (X13/04)	PRESET SELECT 1	These 3 digital input select the active Preset Speed if the Time Of Day Timer feature is not being used
DIGIN 04 (X12/01)	PRESET SELECT 2	
DIGIN 05 (X12/02)	PRESET SELECT 3	
DIGIN 06 (X12/03)	NOT COAST STOP	When FALSE the Drive does not control Fan. The Fan will freewheel.
DIGIN 07 (X12/04)	NOT FIRE MODE	When FALSE activates Fire Mode

* If both Run inputs are TRUE, than MANUAL RUN has the highest priority.

Outputs

Terminal	Function	Comment
ANOUT 01 (X11/03)	FAN SPEED DEMAND	Speed demand as % of maximum Fan speed
ANOUT 02 (X11/04)	FAN LOAD	Calculated fan load as % of maximum fan load
RELAY 01 (X14/01 & X14/02)	RUNNING	When closed the Fan is being driven
RELAY 02 (X14/03 & X14/04)	NOT TRIPPED	When closed the Drive is not tripped
DIGOUT 01 (X12/01)		Terminal used as DIGIN 04
DIGOUT 02 (X12/02)		Terminal used as DIGIN 05
DIGOUT 03 (X12/03)		Terminal used as DIGIN 06
DIGOUT 04 (X12/04)		Terminal used as DIGIN 07
RELAY 11 (X23/01 & X23/02)	FIRE MODE ACTIVATED	When closed Fire Mode is currently Activated
RELAY 12 (X23/03 & X23/04)	FIRE MODE READY	When closed Fire Mode is Ready for Activation
DIGOUT 11 (X20/01)	LOAD WARNING	Abnormal load detection low warning (belt slipping)
DIGOUT 12 (X20/02)	LOAD FAULT	Abnormal load detection low fault (belt broken)
DIGOUT 13 (X20/03)		Not used
DIGOUT 14 (X20/03)		Not used

6 Fan Control Application Manual

Graphical Keypad (GKP) Application Customisation

The fan application adds parameters and menus to the GKP. It also modifies behavior of the and set-up wizard.

Wizard

Under Quick Setup Application:

- 1960: Power Up Start**
- 1958: Use Auto Timer**
- 1959: Run When Non Zero SP**
- 1962: Fire Mode Level**
- 1961: Fire Mode Setpoint**
- 2038: Setpoint Input Max**
- 2039: Setpoint Input Min**

Quick Setup

- 0486: Acceleration Time**
- 0487: Deceleration Time**
- 1916: Preset Speed 0**
- 1917: Preset Speed 1**
- 1918: Preset Speed 2**
- 1919: Preset Speed 3**
- 1920: Preset Speed 4**
- 1921: Preset Speed 5**
- 1922: Preset Speed 6**
- 1923: Preset Speed 7**
- 1958: Use Auto Timer**
- 1959: Run When Non Zero SP**
- 1006: Run Setup?**
- 1141: View Level**

Quick Monitor

- 1997: Load Monitor State**
- 0682: Reference**
- 1924: Selected Preset**
- 0500: Ramp Speed Output**
- 0399: Actual Torque**
- 1964: Fire Mode Activated**
- 1965: Fire Mode Ready**

Setup::Application and Monitor::Application

Include all parameters listed in the table at the end of this manual.

8 Fan Control Application Manual

Abnormal Load Detect

Setup::Application::Abnormal Load Detect
Monitor::Application::Abnormal Load Detect*

When used in the Fan Control Application this feature is used to detect low load indicating belt break or belt slip.

PNO	Parameter Descriptions
<u>1968</u>	Enable Load Monitor Set TRUE to enable this feature.
<u>1969</u>	Startup Delay This sets the duration from when the motor is started until the load monitoring is started. This allows for inaccurate speed/load characterisation and load estimation during start-up period.
<u>1970</u>	Fault Delay This sets the duration from when the load monitor detects a LOAD FAULT until the sequencers stops the motor. This allows for inaccurate speed/load characterisation and load estimation during start-up period.
<u>1973</u>	Low Warning Level This specifies the deviation of the actual load below the expected load which will cause a LOAD LOW WARNING to be reported.
<u>1974</u>	Low Fault Level This specifies the deviation of the actual load below the expected load which will cause a LOAD LOW FAULT to be reported.
<u>1976</u>	Speed 1
<u>1977</u>	Speed 2
<u>1978</u>	Speed 3
<u>1979</u>	Speed 4
	These 4 parameters specify together with the 4 Load parameters below are used to characterise the expected load 'curve' for the actual Speed.
<u>1987</u>	Load 1
<u>1988</u>	Load 2
<u>1989</u>	Load 3
<u>1990</u>	Load 4
	See above Speed parameters.

PNO Parameter Descriptions

1997 Load Monitor State*

This diagnostic reports whether the monitor is monitoring and, if so, if the Load is as expected. This is an enumerated value:

0	MONITORING DISABLED	Either Enable Load Monitor is FALSE or Speed 1 = 0.0%.
1	MONITORING STOPPED	Motor not running, so not monitoring.
2	MONITORING STARTING	Motor started less than Startup Delay ago, so not monitoring yet.
3	LOAD NORMAL	The actual Load is within the expected range, so anomaly detected.
5	LOAD LOW WARNING	The actual Load is below the Low Warning Level but not lower than the Low Fault Level .
7	LOAD LOW FAULT	The actual Load is below the Low Fault Level

1998 Expected Load*

This diagnostic is the calculated Load expected for the current Speed. This is determined from the load 'curve' specified by the **Speed n** and **Load n** parameters and is useful for checking that in the case of incorrect warning or fault reporting.

Functional Description


An estimate of the expected Load for any given Speed is specified using the **Speed n** and **Load n** parameters. Each pair provide a point on the expected Load line.

The Speed parameters must have increasing values. I.e. **Speed 1 < Speed 2 < Speed 3 < Speed 4**.

If not all points are required, a Speed may be set to zero to terminate the sequence. If the actual speed is greater than the last specified point, the line is extrapolated from the previous 2 points.

Speed 1 must be non-zero, otherwise the abnormal load detection feature is disabled.

10 Fan Control Application Manual



Offset from the expected Load line, 2 additional lines are calculated. These are the Warning and Fault detection thresholds. The deviation from normal behavior is determined by the **Low Warning Level** and **Low Fault Level** parameters.

When running, the **Load Monitor State** diagnostic will show if the actual Load is in the NORMAL, WARNING or FAULT region of the graph. Note – for this to report correctly, the **Low Fault Level** must be more negative than the **Low Warning Level**.

If the actual Load remains in the FAULT region for longer than the duration specified by **Fault Delay**, the Drive will stop running.

The **Start Delay** may be used to prevent incorrect warning or fault reported soon after the Run command is issued.

The **Load Monitor State** diagnostic is reset when the Run command is removed.

Fire Mode

Setup::Application::Fire Mode
Monitor::Application::Fire Mode*

Fire mode is intended for use in critical situations where it is imperative for the motor to be kept running if at all possible. In such a situation it may be reasonable to override the Drives' normal protective functions. An example of a critical situation may be a ventilation fan in a stairwell, where continued operation in the event of a fire may assist the safe evacuation of personnel.



Caution When Fire Mode is active the Drive and Motor protection trips are disabled. The use of Fire Mode itself increases the risk of causing a fire by overloading the drive or motor, so it must only be used after assessing the risks.

PNO	Parameter Descriptions									
	<p>Fire Mode Activate</p> <p>Set TRUE to activate the Fire Mode feature. This input may only be set by connection to a digital input as part of the application.</p>									
<u>1961</u>	<p>Fire Mode Setpoint</p> <p>A reference value to be used when Fire Mode is active. Setting a negative setpoint will cause the drive to rotate in reverse direction.</p>									
<u>1962</u>	<p>Fire Mode Level</p> <p>This parameter selects the mode of operation when Fire Mode is activated. It is an enumerated value as follows:</p> <table border="0"> <tr> <td>0</td> <td>DISABLED</td> <td>Fire Mode feature is disabled. The Activate input going high will have no effect.</td> </tr> <tr> <td>1</td> <td>PARTIAL</td> <td>Fire Mode is enabled with "partial mode" trips listed below ignored.</td> </tr> <tr> <td>2</td> <td>FULL</td> <td>Fire Mode is enabled with "full mode" trips listed below ignored.</td> </tr> </table>	0	DISABLED	Fire Mode feature is disabled. The Activate input going high will have no effect.	1	PARTIAL	Fire Mode is enabled with "partial mode" trips listed below ignored.	2	FULL	Fire Mode is enabled with "full mode" trips listed below ignored.
0	DISABLED	Fire Mode feature is disabled. The Activate input going high will have no effect.								
1	PARTIAL	Fire Mode is enabled with "partial mode" trips listed below ignored.								
2	FULL	Fire Mode is enabled with "full mode" trips listed below ignored.								
<u>1963</u>	<p>FM Restart Delay</p> <p>This specifies the duration to wait before attempting to reset a trip.</p>									
<u>1964</u>	<p>Fire Mode Activated</p> <p>When TRUE, this diagnostic, indicates that the Fire Mode is in operation. Trips are being ignored at either the PARTIAL or FULL level and the fire mode Setpoint, which is non-zero, is being followed.</p>									
<u>1965</u>	<p>Fire Mode Ready</p> <p>This diagnostic, when TRUE, indicates that the Fire Mode will operate if the Activate input becomes TRUE. The diagnostic will be FALSE if the fire mode Level is set to DISABLED or the fire mode Setpoint is set to 0.0%.</p>									

12 Fan Control Application Manual

PNO Parameter Descriptions

1966 **FM Last Activated**

A Data and Time diagnostic that records the last time that the Fire Mode was activated. This may be used to validate that the fire mode has been tested. The value is preserved in non-volatile memory. A Real Time Clock (RTC) option must be fitted for the timestamp.

1967 **FM Activation Count**

This diagnostic records the number of activations of the fire mode. This may be used to validate that the fire mode has been tested. The value is preserved in non-volatile memory.

Functional Description

When Fire Mode is activated, the Drive will attempt to run at the speed set by the Fire Mode **Setpoint** parameter even if the Drive was not running at the time. This is regardless of whether in Remote or Local sequencing mode.



Caution If the Drive is powered-up with the Activate input TRUE, the Drive will run immediately without warning.

The only reasons that the drive will not run are:

- **Level** is set to DISABLED
- **Setpoint** is zero
- The Coast Stop input is activated.
- The STO circuit is activated.
- An enabled trip source becomes active.
- A hardware fault



Caution Fire Mode does not override the standard Ramp features. Specifically **0497 Ramp Hold** can prevent the setpoint changing to the Fire Mode **Setpoint** value.

The following table summarizes which trips are disabled in the two modes of operation. Also shown are those trips which are designed to protect the drive.



Caution Disabling the Drive Protection trips will invalidate the drive's warranty. Selecting PARTIAL mode leaves the drive protection features enabled. Selecting FULL mode disables some of the drive protection features.



Caution Regardless of the setting of **Level**, activating Fire Mode may cause damage to the motor or attached equipment.

ID	Trip Name	Disabled in Partial mode	Disabled in Full mode	Drive Protection
1	OVER VOLTAGE			✓
2	UNDER VOLTAGE ⁽¹⁾	Note 1	Note 1	
3	OVER CURRENT			✓
4	STACK FAULT			✓
5	STACK OVER CURRENT			✓
6	CURRENT LIMIT	✓	✓	
7	MOTOR STALL	✓	✓	
8	INVERSE TIME		✓	✓
9	MOTOR I2T	✓	✓	
10	LOW SPEED I	✓	✓	
11	HEATSINK OVERTEMP		✓	✓
12	AMBIENT OVERTEMP		✓	✓
13	MOTOR OVERTEMP	✓	✓	
14	EXTERNAL TRIP	✓	✓	
15	BRAKE SHORT CCT		✓	✓
16	BRAKE RESISTOR	✓	✓	
17	BRAKE SWITCH		✓	✓
18	LOCAL CONTROL	✓	✓	
19	COMMS BREAK	✓	✓	
20	LINE CONTACTOR	✓	✓	
21	PHASE FAIL	✓	✓	
22	VDC RIPPLE		✓	✓
23	BASE MODBUS BREAK	✓	✓	
24	24V OVERLOAD	✓	✓	
25	PMAC SPEED ERROR	✓	✓	
26	OVERSPEED	✓	✓	
27	SAFE TORQUE OFF			

Note 1. The Under Voltage trip is enabled when Fire Mode is active, but the trip level is reduced by 50%.

If a trip source becomes active when the associated trip is disabled the drive will continue to run. This is also the normal behavior of the drive, (when Fire Mode is not active). If the associated trip is designed for drive protection, this will be recorded in non-volatile memory. The recorded values are available to view in the Drives' Trips History.

When Fire Mode is activated and a trip source becomes active and the associated trip is enabled, the Drive will trip, causing the motor to stop. This is similar to the normal behavior of the Drive, (when Fire Mode is not active). However, when Fire Mode is active the firmware within the Drive continues to monitor the trip source, once the trip source has become inactive the drive automatically resets the trip condition and restarts the drive.

Preset Speeds

Setup::Application::Preset Speeds **Setup::Application::Preset Speeds***

The Fan Control Application allows this feature to be either used directly from digital inputs or in conjunction with the Time Of Day Timer. The **Presets** function selects 1 of 8 values to be used as a reference.

PNO	Parameter Descriptions
<u>1916</u>	Preset Speed 0 Preset Speed Output when Selected Preset equals 0
<u>1917</u>	Preset Speed 1 Preset Speed Output when Selected Preset equals 1
<u>1918</u>	Preset Speed 2 Preset Speed Output when Selected Preset equals 2
<u>1919</u>	Preset Speed 3 Preset Speed Output when Selected Preset equals 3
<u>1920</u>	Preset Speed 4 Preset Speed Output when Selected Preset equals 4
<u>1921</u>	Preset Speed 5 Preset Speed Output when Selected Preset equals 5
<u>1922</u>	Preset Speed 6 Preset Speed Output when Selected Preset equals 6
<u>1923</u>	Preset Speed 7 Preset Speed Output when Selected Preset equals 7
<u>1924</u>	Selected Preset* Diagnostic showing selected preset number
	Select 0 This is connected to a Digital Input as part of the selected macro. It provides bit 0 of the Selected Preset number.

PNO Parameter Descriptions

Select 1


This is connected to a Digital Input as part of the selected macro. It provides bit 1 of the Selected Preset number.

Select 2

This is connected to a Digital Input as part of the selected macro. It provides bit 2 of the Selected Preset number.

Functional Description

Select 2	Select 1	Select 0	Selected Preset
FALSE	FALSE	FALSE	Preset Speed 0
FALSE	FALSE	TRUE	Preset Speed 1
FALSE	TRUE	FALSE	Preset Speed 2
FALSE	FALSE	FALSE	Preset Speed 3
TRUE	FALSE	TRUE	Preset Speed 4
TRUE	TRUE	FALSE	Preset Speed 5
TRUE	FALSE	FALSE	Preset Speed 6
TRUE	FALSE	FALSE	Preset Speed 7



Reference

Setup::Application::Reference

The Fan Control Application provides 2 parameters to scale and offset the Setpoint analog input.

PNO	Parameter Descriptions
<u>2038</u>	Setpoint Input Max Sets the full range value for the Setpoint analogue input (ANIN01). It corresponds to the maximum input value of either 10V or 20mA depending on the setting of 0001: Anin 01 Type .
<u>2039</u>	Setpoint Input Min Sets the minimum value for the Setpoint analogue input (ANIN01). It corresponds to the minimum input value of either -10V, 0V, 0mA or 4mA depending on the setting of 0001: Anin 01 Type .

Functional Description

$$\text{setpoint} = ((\text{input} / 100) \times (\text{Setpoint Input Max} - \text{Setpoint Input Min})) + \text{Setpoint Input Min}$$

Sequencing

Setup::Application::Sequencing

The Fan Control Application introduces 3 additional sequencing parameters.

PNO	Parameter Descriptions
<u>1959</u>	<p>Use Auto Timer</p> <p>When TRUE, the AUTO RUN Preset Speed is selected by the Time Of Day Timer function. When FALSE (the default), the Preset Speed is selected by digital inputs.</p>
<u>1960</u>	<p>Start On Setpoint</p> <p>When TRUE and either AUTO RUN or MANUAL RUN is TRUE, the Drive will automatically run whenever the active Setpoint is non-zero.</p>
<u>1961</u>	<p>Power Up Start</p> <p>When TRUE the Drive will immediately run on power up if the AUTO RUN or MANUAL RUN digital input is TRUE. If this parameter is FALSE (the default) a FALSE to TRUE transition of the RUN input is required.</p>

Functional Description

Use Auto Timer:

This allows Time Of Day Timer to override the digital inputs for the selection of the Preset Speed.

Start On Setpoint:

This feature removes the need of applying a run command. Whenever a non-zero ($\pm 0.5\%$) becomes active from either the Preset Speeds or Analog input, a run command is automatically issued.



Caution The Drive may run without warning.

Power Up Start:

This feature removes the requirement of a transition from FALSE to TRUE on the run command. This allows an immediate start of the motor when power is applied to the Drive.



Caution The Drive may run without warning.

Skip Frequencies

Setup::Application::Skip Frequencies

When used in the Fan Control Application a maximum of 2 skip frequencies are available for use.


This function is used to prevent the Drive operating at frequencies that cause mechanical resonance in the load.

PNO	Parameter Descriptions
<u>1908</u>	Skip Freq Band 1 The width of skip band 1 in Hz.
<u>1909</u>	Skip Frequency 1 The centre frequency of skip band 1 in Hz.
<u>1910</u>	Skip Freq Band 2 The width of skip band 2 in Hz.
<u>1911</u>	Skip Frequency 2 The centre frequency of skip band 2 in Hz.


Functional Description

Skip frequencies are used to avoid resonances within the mechanical system. Enter the value of frequency that causes the resonance using a **Frequency** parameter and then program the width of the skip band using its **Band** parameter. The Drive will then avoid sustained operation within the forbidden band as shown in the diagram. The skip frequencies are symmetrical and thus work in forward and reverse.


Setting a **Frequency** to 0.0 disables the corresponding band. Setting a **Band** to 0.0 causes the value of **Band 1** to be used for this band.



The behaviour of this function is illustrated below.



20 Fan Control Application Manual



Time Of Day Timer

Setup::Application::Time Of Day Timer

Monitor::Application::Time Of Day Timer*

This feature allows preset speeds to be selected depending on the time of day and day of week. It requires a Real Time Clock (RTC) to operate, so an IO Option type 7004-01-00 or 7004-03-00 must be fitted.

When used in the Fan Control Application a maximum of 8 speed select events are available for use.

PNO	Parameter Descriptions
<u>2002</u>	Event Days 1
<u>2003</u>	Event Days 2
<u>2004</u>	Event Days 3
<u>2005</u>	Event Days 4
<u>2006</u>	Event Days 5
<u>2007</u>	Event Days 6
<u>2008</u>	Event Days 7
<u>2009</u>	Event Days 8

These 8 parameters specify which day, or days, the event 1-6 applies. Each day is represented as a bit, so that when set indicates that the event is valid on that day. More than one bit may be set to indicate the event is valid on more than one day.

Bit	Hexadecimal	Decimal	Day Of Week
0	01	1	SUNDAY
1	02	2	MONDAY
2	04	4	TUESDAY
3	08	8	WEDNESDAY
4	10	16	THURSDAY
5	20	32	FRIDAY
6	40	64	SATURDAY

22 Fan Control Application Manual

PNO Parameter Descriptions

Example multiple day events:

Bits	Hexadecimal	Decimal	Days Of Week
0,6	41	65	SATURDAY, SUNDAY
1,2,3,4,5	3E	62	MONDAY, TUESDAY, WEDNESDAY, THURSDAY, FRIDAY
0-7	7F	127	Every Day

A value of 0 disables the event.

2013 **Event Time Of Day 1**

2014 **Event Time Of Day 2**

2015 **Event Time Of Day 3**

2016 **Event Time Of Day 4**

2017 **Event Time Of Day 5**

2018 **Event Time Of Day 6**

2019 **Event Time Of Day 7**

2020 **Event Time Of Day 8**

These 8 parameters specify the time of day the event 1-6 occurs.

2024 **Event Select 1**

2025 **Event Select 2**

2026 **Event Select 3**

2027 **Event Select 4**

2028 **Event Select 5**

2029 **Event Select 6**

2030 **Event Select 7**

2031 **Event Select 8**

These 8 parameters specify the **Selected** value when the event 1-6 occurs. This value is maintained until the next timed event occurs. It can be set to any value between 0 and 7 which then is used to select the Preset Speed to be used when the event is active.

2034 **Selected***

This diagnostic is the **Event Select** value for the **Active Event**. If there are no programmed events this will be set to 0.

2035 **Day Of Week Now***

This diagnostic is the day of the week today as determined by the Real Time Clock (RTC). This is an enumerated value:

0 SUNDAY

PNO	Parameter Descriptions
-----	------------------------

1	MONDAY
2	TUESDAY
3	WEDNESDAY
4	THURSDAY
5	FRIDAY
6	SATURDAY

2037	Active Event*
------	----------------------

This diagnostic indicates which of the speed change events last occurred (and is still active). If there are no programmed events this will be set to 0.

Functional Description

A maximum of 6 events may be programmed. Each event is for a time of day on one or more days of the week. A value to be selected is then chosen to be output when the time of day is reached on one of the days that have been specified.

So, each event is programmed with 3 parameters. These are **Event Days**, **Event Time Of Day** and **Event Select**. Unused events must have their **Event Days** set to 0 (default). Events do not need to be declared in chronological order and unused events do not need to be last (i.e. gaps are allowed).

Example Program:

<i>n</i>	Event Days <i>n</i>	Event Time Of Day <i>n</i>	Event Select <i>n</i>
1	3E (Mon, Tues, Wed, Thurs, Fri)	7:00	1
2	40 (Sat)	8:30	1
3	7F (Sun, Mon, Tues, Wed, Thurs, Fri, Sat)	11:00	2
4	7E (Mon, Tues, Wed, Thurs, Fri, Sat)	14:00	3
5	01 (Sun)	14:00	0
6	7E (Mon, Tues, Wed, Thurs, Fri, Sat)	18:00	0

This then has the following behavior:

- Monday to Friday the Preset Speed 1 is selected at 7:00. This remains selected until 11:00 when the Preset Speed 2 is selected. At 14:00 it is changed to Preset Speed 3. Finally, at 18:00 Preset Speed 0 is selected.
- Saturday is the same as Monday to Friday except that the selecting of Preset Speed 1 occurs later at 8:30.
- On Sunday the program just selects Preset Speed 2 at 11:00 and then Preset Speed 0 at 14:00

At power-up, the Time Of Day Timer searches backwards in time (and day) to find the Event that would be active if the power had been on continuously. It then makes this Event active. In the example above, if power-up was 10:00 on SATURDAY then Event 2 would be active, but if at 10:00 on a SUNDAY then Event 6 would be active.

24 Fan Control Application Manual

PNO	Name	Path(s)	Type	Default	Range	Units	WQ	View	Notes	MBus
1901	Selected Application	Setup::Application::App Selection	USINT (enum)	0	0: FAN CONTROL		CONFIG			04329
1908	Skip Band 1	Setup::Application::Skip Frequencies	REAL	0.0	0.0 to 1000.0	Hz	ALWAYS			04343
1909	Skip Frequency 1	Setup::Application::Skip Frequencies	REAL	0.0	0.0 to 1000.0	Hz	ALWAYS			04345
1910	Skip Band 2	Setup::Application::Skip Frequencies	REAL	0.0	0.0 to 1000.0	Hz	ALWAYS			04347
1911	Skip Frequency 2	Setup::Application::Skip Frequencies	REAL	0.0	0.0 to 1000.0	Hz	ALWAYS			04349
1916	Preset Speed 0	Setup::Application::Preset Speeds	REAL	0.0	-100.0 to 100.0	%	ALWAYS			04359
1917	Preset Speed 1									04361
1918	Preset Speed 2									04363
1919	Preset Speed 3									04365
1920	Preset Speed 4									04367
1921	Preset Speed 5									04369
1922	Preset Speed 6									04371
1923	Preset Speed 7									04373
1924	Selected Preset	Monitor::Application::Preset Speeds	USINT	0	0 to 7		NEVER			04475
1958	Use Auto Timer	Setup::Application::Sequencing	BOOL	FALSE			ALWAYS			04445
1959	Start On Setpoint	Setup::Application::Sequencing	BOOL	FALSE			ALWAYS			04447
1960	Power Up Start	Setup::Application::Sequencing	BOOL	FALSE			ALWAYS			04449
1961	Fire Mode Setpoint	Setup::Application::Fire Mode	REAL	0.0	-100.0 to 100.0	%	ALWAYS			04451
1962	Fire Mode Level	Setup::Application::Fire Mode	USINT (enum)	0	0:DISABLED 1:PARTIAL 2:FULL		ALWAYS			04453

PNO	Name	Path(s)	Type	Default	Range	Units	WQ	View	Notes	Mbus
1963	FM Restart Delay	Setup::Application::Fire Mode	TIME	2	0 to 600	s	ALWAYS			04455
1964	Fire Mode Activated	Monitor::Application::Fire Mode	BOOL	FALSE			NEVER			04455
1965	Fire Mode Ready	Monitor::Application::Fire Mode	BOOL	FALSE			NEVER			04457
1966	FM Last Activated	Monitor::Application::Fire Mode	DATE_AND_TIME				NEVER			04459
1967	FM Activation Count	Monitor::Application::Fire Mode	UINT	0	0 to 65535		NEVER			04459
1968	Enable Load Monitor	Setup::Application::Abnormal Load Detect	BOOL	0			NEVER			04463
1969	Startup Delay	Setup::Application::Abnormal Load Detect	TIME	10		s	ALWAYS			04465
1970	Fault Delay	Setup::Application::Abnormal Load Detect	TIME	1		s	ALWAYS			04467
1973	Low Warning Level	Setup::Application::Abnormal Load Detect	REAL	-100.0	-100.0 to 0.0	%	ALWAYS			04473
1974	Low Fault Level	Setup::Application::Abnormal Load Detect	REAL	-100.0	-100.0 to 0.0	%	ALWAYS			04475
1976	Speed 1	Setup::Application::Abnormal Load Detect	REAL	0.0	0.0 to 100.0	%	ALWAYS			04479
1977	Speed 2									04481
1978	Speed 3									04483
1979	Speed 4									04485
1987	Load 1	Setup::Application::Abnormal Load Detect	REAL	0.0	0.0 to 100.0	%	ALWAYS			04501
1988	Load 2									04503
1989	Load 3									04505
1990	Load 4									04507

26 Fan Control Application Manual

PNO	Name	Path(s)	Type	Default	Range	Units	WQ	View	Notes	Mbus
1997	Load Monitoring State	Monitor::Application::Abnormal Load Detect	USINT (enum)	0	0:MONITORING DISABLED 1:MONITORING STOPPED 2:MONITORING STARTING 3:LOAD NORMAL 5:LOAD LOW WARNING 7:LOAD LOW FAULT		ALWAYS			04521
1998	Expected Load	Monitor::Application::Abnormal Load Detect	REAL	0.0	0.0 to 100.0	%	NEVER			04523
2002	Event Days 1	Setup::Application::Time Of Day Timer	BYTE (bitfield)	00	0:Sunday 1:Monday 2:Tuesday 3:Wednesday 4:Thursday 5:Friday 6:Saturday		ALWAYS			04531
2003	Event Days 2									04533
2004	Event Days 3									04535
2005	Event Days 4									04537
2006	Event Days 5									04539
2007	Event Days 6									04541
2008	Event Days 7									04543
2009	Event Days 8									04545
2013	Event Time Of Day 1	Setup::Application::Time Of Day Timer	TIME_OF _DAY	0:00:00	0:00:00 to 23:59:59		ALWAYS			04553
2014	Event Time Of Day 2									04555
2015	Event Time Of Day 3									04557
2016	Event Time Of Day 4									04559

PNO	Name	Path(s)	Type	Default	Range	Units	WQ	View	Notes	Mbus
2017	Event Time Of Day 5									04561
2018	Event Time Of Day 6									04563
2019	Event Time Of Day 7									04565
2020	Event Time Of Day 8									04567
2024	Event Select 1									04575
2025	Event Select 2									04577
2026	Event Select 3									04579
2027	Event Select 4									04581
2028	Event Select 5									04583
2029	Event Select 6									04585
2030	Event Select 7									04587
2031	Event Select 8									04589
2034	Selected	Monitor::Application::Time Of Day Timer	USINT				NEVER			04595
2035	Day Of Week Now	Monitor::Application::Time Of Day Timer	USINT (enum)	0	0:SUNDAY 1:MONDAY 2:TUESDAY 3:WEDNESDAY 4:THURSDAY 5:FRIDAY 6:SATURDAY		NEVER			04597
2037	Active Event	Monitor::Application::Time Of Day Timer	USINT	0	0 to 6		NEVER			04601
2038	Setpoint Input Max	Setup::Application::Reference	REAL	100.00	-200.00 to 200.00		ALWAYS			04417
2039	Setpoint Input Min	Setup::Application::Reference	REAL	0.00	-200.00 to 200.00		ALWAYS			04419

Parker Worldwide

AE – UAE, Dubai

Tel: +971 4 8127100
parker.me@parker.com

AR – Argentina, Buenos Aires

Tel: +54 3327 44 4129

AT – Austria, Wiener Neustadt

Tel: +43 (0)2622 23501-0
parker.austria@parker.com

AT – Eastern Europe, Wiener Neustadt

Tel: +43 (0)2622 23501 900
parker.easteurope@parker.com

AU – Australia, Castle Hill

Tel: +61 (0)2-9634 7777

AZ – Azerbaijan, Baku

Tel: +994 50 2233 458
parker.azerbaijan@parker.com

BE/LU – Belgium, Nivelles

Tel: +32 (0)67 280 900
parker.belgium@parker.com

BR – Brazil, Cachoeirinha RS

Tel: +55 51 3470 9144

BY – Belarus, Minsk

Tel: +375 17 209 9399
parker.belarus@parker.com

CA – Canada, Milton, Ontario

Tel: +1 905 693 3000

CH – Switzerland, Etoy

Tel: +41 (0)21 821 87 00
parker.switzerland@parker.com

CL – Chile, Santiago

Tel: +56 2 623 1216

CN – China, Shanghai

Tel: +86 21 2899 5000

CZ – Czech Republic, Klecany

Tel: +420 284 083 111
parker.czechrepublic@parker.com

DE – Germany, Kaarst

Tel: +49 (0)2131 4016 0
parker.germany@parker.com

DK – Denmark, Ballerup

Tel: +45 43 56 04 00
parker.denmark@parker.com

ES – Spain, Madrid

Tel: +34 902 330 001
parker.spain@parker.com

FI – Finland, Vantaa

Tel: +358 (0)20 753 2500
parker.finland@parker.com

FR – France, Contamine s/Arve

Tel: +33 (0)4 50 25 80 25
parker.france@parker.com

GR – Greece, Athens

Tel: +30 210 933 6450
parker.greece@parker.com

HK – Hong Kong

Tel: +852 2428 8008

HU – Hungary, Budapest

Tel: +36 1 220 4155
parker.hungary@parker.com

IE – Ireland, Dublin

Tel: +353 (0)1 466 6370
parker.ireland@parker.com

IN – India, Mumbai

Tel: +91 22 6513 7081-85

IT – Italy, Corsico (MI)

Tel: +39 02 45 19 21
parker.italy@parker.com

JP – Japan, Tokyo

Tel: +81 (0)3 6408 3901

KR – South Korea, Seoul

Tel: +82 2 559 0400

KZ – Kazakhstan, Almaty

Tel: +7 7272 505 800
parker.easteurope@parker.com

MX – Mexico, Apodaca

Tel: +52 81 8156 6000

MY – Malaysia, Shah Alam

Tel: +60 3 7849 0800

NL – The Netherlands, Oldenzaal

Tel: +31 (0)541 585 000
parker.nl@parker.com

NO – Norway, Asker

Tel: +47 66 75 34 00
parker.norway@parker.com

NZ – New Zealand, Mt Wellington

Tel: +64 9 574 1744

PL – Poland, Warsaw

Tel: +48 (0)22 573 24 00
parker.poland@parker.com

PT – Portugal, Leca da Palmeira

Tel: +351 22 999 7360
parker.portugal@parker.com

RO – Romania, Bucharest

Tel: +40 21 252 1382
parker.romania@parker.com

RU – Russia, Moscow

Tel: +7 495 645-2156
parker.russia@parker.com

SE – Sweden, Spånga

Tel: +46 (0)8 59 79 50 00
parker.sweden@parker.com

SG – Singapore

Tel: +65 6887 6300

SK – Slovakia, Banská Bystrica

Tel: +421 484 162 252
parker.slovakia@parker.com

SL – Slovenia, Novo Mesto

Tel: +386 7 337 6650
parker.slovenia@parker.com

TH – Thailand, Bangkok

Tel: +662 717 8140

TR – Turkey, Istanbul

Tel: +90 216 4997081
parker.turkey@parker.com

TW – Taiwan, Taipei

Tel: +886 2 2298 8987

UA – Ukraine, Kiev

Tel +380 44 494 2731
parker.ukraine@parker.com

UK – United Kingdom, Warwick

Tel: +44 (0)1926 317 878
parker.uk@parker.com

US – USA, Cleveland

Tel: +1 216 896 3000

VE – Venezuela, Caracas

Tel: +58 212 238 5422

ZA – South Africa, Kempton Park

Tel: +27 (0)11 961 0700
parker.southafrica@parker.com

European Product Information Centre

Free phone: 00 800 27 27 5374

(from AT, BE, CH, CZ, DE, EE, ES, FI, FR, IE, IL, IS, IT, LU, MT, NL, NO, PT, SE, SK, UK)

**Parker Hannifin Manufacturing Limited
Automation Group, SSD Drives Europe,**

New Courtwick Lane,

Littlehampton, West Sussex. BN17 7RZ

Office: +44 (0)1903 737000

Fax: +44 (0)1903 737100

www.parker.com/ssd

