

Installation Instructions

1. Align foam block with corner window of housing.
2. Fully seat foam holder before installing filter into housing.
3. Install filter into housing.

